ENPHASE INVERTER RESTART PROCEDURE

TO RESET YOUR ENPHASE SYSTEM, WE NEED TO PHYSICALLY POWER CYCLE IT

1. Turn off the “Main Switch Inverter Supply” and all circuit breakers in the Combiner Box.

2. Wait: Allow a few minutes for the system to fully de-energize.

3. Turn On “Main Switch Inverter Supply” and all circuit breakers in the Combiner Box.