


Fronius GEN24 Inverter Restart Procedure




STEP 01

Turn off the "Inverter AC Isolator" located next to the inverter, OR the "Main Switch (Inverter Supply)" located in the main switchboard of the house or meter box.

Turn off the "PV Array DC Isolator" which is the black rotary switch located on the body of the inverter.

STEP 02



LOCKED/OFF (turned to left) **1**

OFF SWITCH **2**

ON SWITCH **3**

STEP 03



FOR A FEW MINUTES

STEP 04

Turn on the "PV Array DC Isolator" first, and then the "AC Isolator" second (Step 2 and then Step 1)

